

11 SPARE PARTS




Fig.13 Exploded views

12 SPARE PARTS LIST

Ref.	Description	Product	Part No.
1A 2A 2B	Button, indice, & screw kit	Nuastyle	E960 615AA
1B	Cover cap, non-res, AS logo	Contour21	A962 017AA
3	Handle retaining screw	All	A961 950NU
4A	Lever handle	Nuastyle	E960 669AA
4B	Lever handle	Contour21	A961 823AA
5	Thermostatic cartridge	All	A962 280NU
5	Thermostatic cartridge (10 bulk pack)	All	F960 879NU
6	Couplers –copper tails PAIR	A4169/A6430	F960 882NU
7A	Complete outlet with STD, F/S insert & seal	Nuastyle	A961 625AA
7B	Optional Armitage Bioguard (10 bulk pack with AVK)	All	F961 138AA
7C	Outlet cpl. with AVH, 4.7 L/min PCA insert, seal & AVK.	Contour21	B960 859AA
7D	F/S insert only	Contour21	B960 860NU
7E	2 lpm Spray Insert	A4169	E960 735NU
8	Tap deck seal	Nuastyle	E960 059NU
9A	Back-nut M28x1.5	Nuastyle	H960 098NU
9B	Clamping kit & seal	Contour21	A963 381NU
10	10mm copper tails - PAIR	A4169/A6430	E960 644NU
10A	Flexible inlet tail M10 long	A4169/S7449	E960 642NU
10B	Flexible inlet tail M10 short	A4169/S7449	E960 589NU
11	Isolating valves-PAIR	All	E960 613NU
12	Flow regulator	All	A962 570NU

Abbreviations used:

STD : STandarD housing has spanner flats.

AVH : Anti-Vandal Housing requires special key.

AVK : Anti-Vandal key

F/S : Flow Straightener with full flow.

PCA: Pressure Compensating Aerator.

Most spares are interchangeable between products, please contact customer care.